



# Resetting and replacement Electronic knob ELS & ENiQ Pro

Q: What do I have to do to replace the body of an ENiQ Pro or ELS Pro?

A: During replacement of **ENiQ Pro** -> **ELS Pro** electronics, the cylinder must be decoupled using the following steps:

1. The cylinder must be decoupled from the system via Device Management.
2. The ELS Pro electronics may only be fitted to the body assembly after this has taken place.
3. First initialisation (marrying) of the ELS Pro electronics with the body assembly using the **ELS master card**.

**Note on the controller: the cylinder now flashes blue (as with an RF wake-up card) when a transponder is presented.**

A: During replacement of **ELS Pro** -> **ENiQ Pro** electronics, this must take place via the master card using the following steps:

1. Remove knob cap
2. Unplug battery
3. Position the master card in the cylinder reading field
4. Insert the battery and wait until the cylinder flashes red and green alternately
5. Unplug the battery again
6. Remove the cylinder from the reading field of the master card
7. Insert the battery again

**Note on the controller: the cylinder now flashes blue (as with an RF wake-up card) when a transponder is presented**

8. Couple by means of ENiQ Device Management